

# Notice des répliques WE

[www.paulette-airsoft.com](http://www.paulette-airsoft.com)

[www.aliz.fr](http://www.aliz.fr)



**Vente et utilisation interdites aux mineurs**



**Culasse mobile (Reculer-la pour charger et amorcer le tir)**



**Cran de sûreté**

**Déblocage du chargeur  
(appuyer et faire descendre  
le chargeur)**

**sécurité  
(empêche  
de tirer  
lorsque la  
réplique  
n'est pas  
tenue en  
main**

## I. Chargement :

Retirez le chargeur en appuyant sur le bouton rond en haut de la cross (indiqué en photo ci-dessous). Insérez les billes une à une dans le chargeur en tendant le ressort vers le bas. Replacez le chargeur dans le réceptacle.



## II. Charger en gaz

Une fois que vous avez mis les billes dans le chargeur, alimentez-le en gaz

Comme suit :

Chargeur retiré de la réplique. Bonbonne de gaz en haut et chargeur en bas.

Exercez une pression sur la bonbonne dans le sens de la flèche sur la photo.

Assurez vous que la tige de la bonbonne se soit bien connectée dans la tige à la base du chargeur.



Type de gaz à utiliser : Green gaz (trouvable en armurerie et revendeurs Airsoft).


La tige fournie dans le pack sert à nettoyer le canon ou aller chercher une bille qui serait restée coincée

## Puissance : inférieure à 2 joules


● Wear protective eye wear & face mask when playing AirSoft Sports.



● NEVER brandish or fire AirSoft Sport Gun at animal, or people beyond a certified and regulated AirSoft Sport arena. Brandishing a gun in public is against the law, serious consequences could arise.



● Read and understand the operating and safety manual before using your AirSoft Sport Gun.



● Do not look directly into the gun barrel to avoid accidental discharge of BB.



● Be aware of your surroundings to avoid accidents.



● ALWAYS transport an AirSoft Sport Gun inside a locked carrying case. Make sure it's unloaded. Never carry your AirSoft Sport Gun in open view as a concealed weapon, or brandish an AirSoft Sport Gun in public.



● Do not disassemble or modify your AirSoft Sport Gun, doing so will void all warranty. Service by authorized centers only. Removal of the orange safety barrel marking is a federal offense.



● Always install safety barrel plug when you are not using your AirSoft Sport Gun.

